SHIELD

SHIELD TOP CASE L

USER MANUAL

FURCHTLOS

CASE VARIANTS

This instruction manual applies to all variants of the SHIELD L case.

SHIELD L LUXE

FU11TCUP000L16EX

FU11TCUP000L14EX

FU11TCUP000L25EX

SHIELD L

FU11TCXX000L16EX

FU11TCXX000L14EX

FU11TCXX000L25EX

OPTIONAL ACCESSORIES

Below are the optional accessories that can be purchased separately.

Black color lid
FU11TCXX410001EX

White color lid
FU11TCXX410002EX

Comfort backrest*2
FU11TCXX420001EX



Silver color lid
FU11TCXX410004EX

Red color lid
FU11TCXX410005EX

OPENING AND CLOSING THE CASE

1. To open the case, turn the key 20° counterclockwise. The lid will pop up slightly when the case is unlocked. Once the case is unlocked, use your hand to lift the lid fully open.





2. To close the case, press down on the lid until the lock engages.



WARNING!

Be aware that the case will automatically lock when fully closed.

Pay attention not to close the keys inside the case!

MOUNTING THE TOP CASE

⚠ To mount the SHIELD L Top Case, it's necessary to first install the Plastic Support Plate L or a compatible Furchtlos rear rack (fitting instructions included with relevant product).

1. Insert the rear legs of the case into the corresponding holes in the plate.





2 Insert the key into the case and turn it 45° clockwise.



3 Press the button in the bottom of the case and lower it onto the plate to engage the wedge. Check that the top case is securely attached and cannot move freely.



REMOVING THE TOP CASE

1 Insert the key into the case and turn it 45° clockwise.



2 Press the button in the bottom of the case and lift it away from the plate.



WARNINGS AND GUIDELINES

WARNING!

Please read the user manual carefully and follow the recommended assembly and care instructions.

It's recommended to check that the case is securely attached before each operation of the motorcycle.

Never drive the motorcycle with a case that is overloaded, that is not fully closed, that is not properly secured, or with damage that may affect the safe operation of the vehicle.

Please be mindful of how you pack your luggage. Cases should not be used to store flammable or explosive items or fragile items that can be easily broken.

CLEANING & MAINTENANCE

The cases should only be cleaned with water and a mild soap and dried with a soft cloth.

Do not use car wash detergents or other harsh cleaning agents or chemicals.

Do not use a pressure washer.

When the surface material is exposed to direct sunlight for a long time or is affected by environmental factors (such as haze, acid rain, etc.), the color may fade or change.

If the product is contaminated with gasoline or similar substances it must be cleaned immediately!

FURCHTLOS does not assume any responsibility for product damage and color change caused by improper cleaning and maintenance!

CLEAN WITH A DAMP CLOTH OR SOFT SPONGE

DO NOT PRESSURE WASH

CLEAN GASOLINE OR OTHER SPILLS IMMEDIATELY!

DO NOT USE CHEMICALS OR HARSH CLEANING AGENTS

VIDEO TUTORIAL

WARRANTY REGISTRATION

FOLLOW & TAG US
@FURCHTLOSMOTO_

www.furchtlos-moto.com