

EVEREST

EVEREST ROLL BAG

USER MANUAL



FURCHTLOS

INCLUDED

EVEREST Roll Bag
x1



Detachable shoulder strap
x1



Universal Fixation Straps
x4



CLOSING THE BAG

1

It's recommended to first close one side of the bag by rolling the mouth closed. The mouth of the bag should be rolled at least three times for a watertight seal.



2

Fasten the buckles on both sides of the bag. Then place your belongings inside the bag from the open end.



3

After placing your items inside, roll the open end of the bag closed and fasten the buckles on either side. If needed, use the air valve to release any extra air inside the bag.



4

Pull the loose webbing ends to tighten all 4 straps. After tightening, the excess webbing length can be folded and secured with the hook and loop strip.

- 5** To maintain a tight seal, take the G-hook strap on each end of the bag and hook the G-hook into the MOLLE webbing panel on the top of the bag, as shown below. Pull the loose webbing ends to tighten the straps as much as possible, then secure them with the elastic band on each strap.



BAG X BAG ASSEMBLY

- 1** Place the EVEREST Roll Bag on top of the EVEREST Duffel Bag.
- 2** Using the Bag X Bag Accessory Strap (sold separately), place the non-adjustable G-hook in the webbing loop of the EVEREST Duffel Bag, as shown in the image below.



- 3** Then place the adjustable G-hook in the webbing loop of the Roll Bag. Pull the loose webbing end to tighten the strap as much as possible. After tightening, the excess webbing length can be folded and tucked inside the elastic band.



- 4** Repeat Steps 2-3 for all 4 straps. Ensure the straps are well tightened and the bags are securely attached before each operation of the vehicle.

UNIVERSAL STRAP ASSEMBLY

- 1** Locate 4 secure mounting points on the frame of the motorcycle, 2 facing the front of the bike and 2 facing the rear. Using the fixation strap included, pass the G-hook around the mounting point and through the loop on the other end of the strap. Pull tight to ensure the strap is securely attached.



- 2** Place the bag in the desired position on the motorcycle. Hook the G-hooks into the corresponding webbing loops on the roll bag as shown below, then pull the loose webbing ends to tighten the straps as much as possible. Afterwards, the excess webbing length should be folded and secured inside the elastic band on each strap.



FAST FIT MECHANISM ASSEMBLY

- 1 Open the hook and loop straps on the back panel to access the back pocket. With the mechanism holes facing upwards, slide the Fast Fit mechanism plate into the pocket, so the mechanism holes align with the cutouts in the pocket, then reattach the hook and loop straps to firmly secure the mechanism.



Ensure the circled areas are well aligned.



Furchtlos Plastic Plate Variant



Furchtlos Aluminum Plate Variant



Furchtlos Side Frame Variant



GVMK Variant

FAST FIT TAIL BAG ASSEMBLY

- 1** To assemble the Roll Bag to a support plate, first position the legs of the mechanism in the corresponding holes in the plate, then push down to engage the front wedge.

Furchtlos Aluminum Plate Variant:



Furchtlos Plastic Plate Variant:



FAST FIT TAIL BAG REMOVAL

- 1** To remove the bag from the motorcycle, open the flap to access the key. Insert the key and turn it 90 degrees. With the key turned, push the button down to release the lock. Once the lock is released, the bag can be lifted away from the motorcycle.



FAST FIT SIDE BAG ASSEMBLY



Note: When assembling the Roll Bag as a Side Bag, the user is responsible for ensuring that no part of the bag, including the webbing straps, has close contact with high temperature areas such as the exhaust pipe which can cause damage to the bag or create an unsafe driving condition.

1

Position the bag so the fixation points on the mechanism align with the points on the side frame. Then push the top of the bag towards the frame to engage the wedge.

Furchtlos Side Frame Variant:



GVMK Variant:



FAST FIT SIDE BAG REMOVAL

1

To remove the bag from the motorcycle, open the flap to access the key. Insert the key and turn it 90 degrees. With the key turned, push the button down to release the lock. Once the lock is released, the bag can be lifted away from the motorcycle.



WARNINGS & GUIDELINES

WARNING!

Please read the user manual carefully and follow the recommended assembly method.

It's recommended to check that the bag is securely attached before each operation of the motorcycle.

Do not drive the motorcycle with a bag that is not fully closed, is not properly secured, or in any other condition that may affect the safe operation of the vehicle.

Ensure that no part of the bag, including the fixation straps or other accessories, has close contact with high temperature areas such as the exhaust pipe.

CLEANING & MAINTENANCE

To maintain a nice appearance, it's recommended to use silicone lubricant spray and a soft cloth to wipe the bags clean.

Do not use harsh cleaning agents, chemicals or high pressure cleaners.

When the surface material is exposed to direct sunlight for a long time or is affected by environmental factors (such as haze, acid rain, etc.), the color may fade or change.

If the product is contaminated with gasoline or similar substances it must be cleaned immediately!

FURCHTLOS does not assume any responsibility for product damage and color change caused by improper cleaning and maintenance!



CLEAN WITH A DAMP CLOTH OR
SOFT SPONGE



DO NOT PRESSURE WASH



CLEAN GASOLINE OR OTHER
SPILLS IMMEDIATELY!



DO NOT USE CHEMICALS OR HARSH
CLEANING AGENTS



VIDEO TUTORIAL



WARRANTY REGISTRATION



FOLLOW & TAG US
@FURCHTLOSMOTO

www.furchtlos-moto.com